



# linkIT-Control4

# Link your motors by integrating Gaposa radio motors into Control4's industry-leading smart home control solutions.

LinkIT allows for group and individual motor control. Simply connect by using our approved connection cable to your controller and install the easy to use integration driver. Each LinkIT can support up to 24 channels depending on model number.

# **TECHNICAL CHARACTERISTICS**

- 🔲 Individual or group control
- 🔲 16 or 24 individual channels
- Tilting mode
- Intermediate position
- LED for feedback
- Reset and programming buttons
- Cables available for easy connection

Voltaje de entrada del Hub	5V
Potencia de entrada del Hub	0.3 A Max.
Frecuencia	868.30 MHz
Conexión	Wi-Fi
Red Wi-Fi	2.4 GHz únicamente
Alcance	30 mt / 98 feet
Grado de protección	IP20
Temperatura de funcionamiento	0°C a 60°C / 32°F a 140°F



EN

# Hardware

Comes with 2A, 5V micro-USB power supply and DB9 adapter cable. It is possible to install more than one LinkIT provided your Controller has the requisite number of RS232 ports or a Remote RS232 - TCP/IP Convertor is used. No daisy chain possible









USAGE	RJ9 PIN	DB9 PIN
5 Volt Power	1	NA
TXD	2	2
RXD	3	3
GND	4	5

Note: RS232 connection is made via RJ9 Socket.

Warning: check for crossover of pins 2 & 3 depending on the equipment used.

5V Pin is optional and is provided to allow LinkIT to be powered via the RJ9 socket.

This is for advanced installation only and should not be used alongside the 5V micro USB input.

# **Cabling distance**

15 meters or more if special cables are used. Cable options:

Reference	Description
	Serial connector with RJ9

#### **CONTROL4 DRIVER:**

Control4 version required: 2.9.0 minimum Initial release date: 01-01-2020 Last modified: 01-01-2020

#### **Driver functions**

This driver enables you to use the Gaposa LinkIT in a Control 4 installation. The driver consists of a main gateway driver which communicates with LinkIT by RS232. Slave drivers then provide control over 1 motor (blind) address. The driver can control up to 16 or 24 motors.

#### Important - Trying to control more motors than your LinkIT model can control will result in a failure to operate.

#### Maximum number of linkITs

It is possible to install more than one LinkIT provided your Controller has the requisite number of RS232 ports or a Remote RS232 - TCP/IP Convertor is used.



# Driver installation

Download the driver from http://www.gaposa.it/eng/linkit/ Extract the drivers from the zip file to MyDocuments/Control4/Drivers folder on your PC.

#### **First Installation**

If this is your first installation using the driver, please make sure you read the whole of this manual before touching any equipment.

We highly recommend setting up the driver in your office or shop first before installing it on site.

The RJ9 cable should be connected between the LinkIT and the Control4 controller before powering up. With the RS232 cable in place ensure LinkIT is powered from a 2 Amp 5Volt USB power source.









## **CONFIGURING THE DRIVER For IP wireless connection**

# Important - You must install the Gaposa Blind RS232 IP interface driver first before adding any shade drivers. Add Gaposa Shade IP interface driver as pictured below:

Composer Pro 3.2.4 / OS Management 3.1.	3 - (Local)				– o ×
File Driver Go Tools Feedback Help					
System Design	Properties	Properties Summary	/ List View	Items	
System	Properties			Locations Discovered	My Drivers Search
~ ^ <b>v</b> 0 9	Properties Actions Documentation	ion Lua			~ Clear
New Project     Home		Driver Status		Local Online Co	ertified Advanced ~
E Main	Driver Version	102_Beta-1		Category - All	~
E Room	Operational Status	ОК		Type - All	~
Remote Hub		Configuration		Manufacturer - All	~
- Shades	Poll Interval (seconds)	10	÷	Control - All	~
	Port Number	80	\$	Driver Suggestions	Sort Relevance ~
	Serial Number	E868E708226C		Gaposa Shade Group	
		Please locate this on the bottom of your Hu	b	Gaposa   Blinds	5/6/2022
		Device Status		Gaposa Shade	
				Gaposa   Blinds	5/6/2022
	Channel Limit	32		Gaposa Shade RS232 In	terface 📃
	Software Version	2.1.5		Gaposa   others   Serial	5/6/2022
	WIFI Signal	-28		Gaposa Shade IP Interfac Gaposa   others   IP	5/6/2022
1	Province 1	494			

#### Bind the Driver to the Linkit hub.

The hub serial **#** is located on the bottom of your hub or it can be retrieved from the Hub status on your Rollapp as pictured:

🕢 Hub Status	0
Name	Linkitwifi
Serial	E868E708226C
Shade Limit	32
Frequency	434 MHz
IP Address:	10.1.10.65
Subnet:	255.255.255.0
Status:	×
Wifi Signal:	
	UnLink Hub

# Bind the IP Driver to the IP controller as pictured:



#### Add the shade driver to the room the blind is located in as pictured

		Properties Sciencely LinkView	Rems	
palare.	Projetes		Locationa Discovered My Driver	a Seath
- A - 09	Blind Type Park		antina	- Ow
E . Nate			Band Conv Contest	Marial -
0-12 House	Ellind Movement Oper-Ones	*	Cempry - All	
G 🖉 Room	Keyped Button Cost Ar	N	Yype-At	
Concer Halt	Open ··· Doeed		Harufacturer - 28	
Date .	1		Cureat - HE	
States 2	Advanced Properties			de ante
	Properties Actions Documentation Los			
		Status	Gapona Shade Group	
	Driver Version	102_fate 1	Gapress   Birds	54/2522
	Operational Status	06	Gapsea Shade	
	No. Contraction	Shade Configuration	Gageroa Shada P0232 Interface	
	Overed ID	81	Gapters ( others ) Senal	56202
		Enter the Bask and Duavel 10, + g 0,1	Gapesa Bhade # Interface	
	Can Step		Congress manual	
-	GenvOrse Trans (seconds)	• 8		
System Design	1	Datas		
Gamestions	Detrug Mude	or and the second se		
> Media	Dates Schendung			
C) Agents	Consignments			
0) Programming	Debug Level	*	John March March 19	

# CONFIGURING THE DRIVER

Important - You must install the Gaposa Blind RS232 interface driver first before adding any slave drivers.

#### Add master driver

Locations	Discovered	My Driver	s Sea	irch
gaposa				~
Local	Online 🗌 Certif	ied Only	Clear Se	arch
- All Categories	-			~
Type:				
- All Types -				~
Manufacturer:				
- All Manufactu	rers			~
Control Method	All Methods	<ul> <li>✓ Sort:</li> </ul>	Relevance	~
Gaposa E	lind			
Janus	11/3/2019 5:1	3 PM	e	ocal
Gaposa E	lind RS232	Interface		
	441010040 5 4	0.014		-

#### Bind the Driver to the correct RS232 port on the controller

Control & Audio Video Connections							
Gaposa Blind RS232 Interfa	ce						
Name	Туре	Connection		Input/Output	Co	nnected To	
Control Inputs							
📟 Serial RS-232	Control	RS_232		Input	CA	-1->SERIAL	
Control Outputs							
🗳 Gaposa Blind Proxy	Control	GAPOSA_BLIN	ID	Output	Blir	nds->Gaposa Blind Proxy	
RS_232 Output Devices							
Device		Name	Location			Connections	
CA-1		SERIAL	Room			Gaposa Blind RS232 Interface->Serial RS-232	

#### Add the slave blind driver to the room the blind is located in

gaposa					~
Local Category:	Dnline 🗌 Cer	tified Or	nly	Clear Se	arch
- All Categories	-				~
Туре:					
- All Types					~
Manufacturer:					
- All Manufactur	ers				~
Control Method:	All Methods	$\sim$	Sort:	Relevance	~
Gaposa B	lind				
Janus	11/3/2019 5	:13 PM		La	cal

#### Configure the blind driver; see below for details:

dvanced Prop	perties			
Properties	Actions	Document	ation Lua	
Driver Vers	sion		200	
Blind Chan	nnel ID		1	*
Set Level			Not available	~
Can Stop			Yes	~
Open/Clos	e Travel '	Time (sec	15	×
Debug Mo	de		Off	~
Debug Sut	bsystems			
Debug Lev	vel		0	-

#### PAIRING MOTOR

Before a screen can be controlled from LinkIt/Control 4, the screen must be synched into RollApp.

- 1. Create a room
- 2. Into the room create the device
- 3. From the handheld remote already paired with the screen, move the screen to the middle. Press and hold in the sync button on the back of the remote until the screen starts moving. As it moves, let the sync button go and press the corresponding Up or DOWN button into Rollapp. Press submit and go to the next one.
- 4. Once you paired all the devices into Rollapp go to the SETUP page of Rollapp and open the "integration" section
- 5. Copy your ID channels and paste in the shade driver of your composer
- 6. Test you can control the devices from composer and C4 app. Before a motor can be controlled LinkIT must be paired to the motor. There are two options:
- 7. To control a group of motors, add the group driver and follow the instructions as indicated into C4 composer. \*No more than 8 motors per group.

Id	Location	Name	Stat
0,1	Office	Shade 1	
0,2	Office	Shade 2	
0,3	Office	Shade3	
0,4	Office	Shade 4	

#### Integration

#### **CONFIGURATION OPTIONS**

#### **Driver Version:**

Version of Currently installed driver

#### Blind Channel ID

Each Motor that requires control will need a separate ID (see warning above for the maximum allowed channel allocation)

#### Set Level

Control4 can simulate opening the blind to a pre-set position (determined by percentage open). This is done by timing the travel from fully closed to fully open. To use this feature the travel time must be entered. If you wish to disable this, please set this to "not available" and the open/close travel time to "0".

#### Stop

Stop function Enabled / Disabled

#### **Open/Closed Time**

Set the value to be used with Set Level

#### **Debug Options:**

These are functions reserved for technical support do not alter these unless directed to do so.

#### Allocating a channel ID:

1. When you have correctly allocated a Blind Channel ID in the properties tab, switch to the Actions tab. (See screenshot below)

- 2. Press Add Motor and the blind will move up or down.
- 3. Follow the motor Handset pairing guide to complete the addition of the LinkIT as a transmitter.
- 4. To delete follow the guide and instead use the Delete Motor option.

To add to an existing motor, open the channel with the handset first.



Gaposa srl - via Ete, 90 - 63900 Fermo - Italy T. +39.0734.220701 - F. +39.0734.226389 - info@gaposa.com www.gaposa.com